

Victor Reader Trek Cheat Sheet

Leader Dogs for the Blind

Record Landmark:

1. Tap RECORD Key
2. Record (speak) landmark name into the microphone
3. Listen for VR Trek to play back recording

Guidance to Landmark:

1. Tap GO TO Key
2. Use 4 and 6 as LEFT and RIGHT arrow to find desired landmark
3. Tap CONFIRM or # to select desired landmark
4. Tap CONFIRM or # to select pedestrian mode, press and hold if in vehicle
5. Follow route instructions

Open Area Mode:

“You will be guided as the crow flies”

- Press and hold OPEN AREA (6) to toggle in and out of Open Area mode
- Distance will be announced every 10 seconds and decrease as approaching destination

Using Clock Face Directions

- 11-1 Continue straight
- 2-4 Begin searching for right turn
- 5-7 Turn around
- 8-10 Begin searching for left turn

Helpful Tools:

- Press and hold 0 for Key Describer Mode
- Tap EXPLORE key to deactivate routes or cancel
- To lock: press and hold *

- To unlock: press 1, 2, 3
- To connect to Bluetooth: tap 7, arrow to enable Bluetooth
- To restart: press and hold POWER for seven seconds
- Toggle volume, speed, & tone: tap POWER when turned on,
toggle using volume arrows

*Check out the HumanWare Buddy App for a How to Guide and other
support*