

Victor Reader Trek Cheat Sheet

Leader Dogs for the Blind

Record Landmarks:

1. Tap RECORD Key
2. Record (speak) landmark name into the microphone
3. Listen for Trek to play back recording

Guidance to Landmark:

1. Tap GO TO Key
2. Use 4 and 6 as LEFT and RIGHT arrow to find desired landmark
3. Tap CONFIRM or # to select desired landmark
4. Tap CONFIRM or # to select pedestrian mode, press and hold if in vehicle
5. Follow route instructions

Other Helpful Tools:

- Press and hold 0 for Key Describer Mode
- Tap EXPLORE to deactivate routes or cancel
- To lock: press and hold *
- To unlock: press 1, 2, 3
- To connect to Bluetooth: tap 7, arrow to enable Bluetooth
- To restart: press and hold power for seven seconds
- Toggle volume, speed, and tone: tap power button when turned on, toggle using volume arrows

Open Area Mode:

“You will be guided as the crow flies”

- Press and hold OPEN AREA (6) to toggle in and out of Open Area mode

Using Clock Face Directions

- 11-1 Continue straight
- 2-4 Begin searching for right turn
- 5-7 Turn around
- 8-10 Begin searching for left turn

Distance will be measured in feet and decrease as approaching destination.

Updates will be given every 10 seconds

Check out the Humanware Buddy App for a How to Guide and other support