

Navigating Web Pages Using Brailiant

Author: Peter Tucic, HumanWare

Common Commands

- Dot 4 with space bar: Move the focus down one line and read it aloud.
- Dot 1 with space bar: Move the focus up one line and read it aloud.
- Command keys 3-4-6: List all links on the page.
- Command keys 2-3-6: List all headings on the current page.
- Command keys 1-2-3-5-6: Move back to the previous page.
- Braille input keys 1-2-5 (h): Move to the next heading.
- Braille input keys 1-2-5-7 (h with backspace): Move to the previous heading.
- Space with dots 2-8, followed by d: Move focus to the address bar.
- Space with m: Move focus to the menu bar.
- Braille Input keys 1-5 (e): Move focus to the next edit box.